

1/23

FIG.1






FIG.2




3/23

FIG.3




4/23

FIG.4




5/23

FIG.5




6/23

FIG.6




7/23

FIG.7




8/23

FIG.8



9/23

FIG.9



10/23

FIG.10





FIG.11



12/23

FIG.12

NODE ID	USER ID	NODE ID (FUNCTION)	USER NAME	VIEWING	CHANGE	EXE- CUTION	MANAGE- MENT
101	3	—	UNREGISTERED USER	×	×	×	×
101	11	—	ROBOT OPERATOR	○	○	○	○
101	—	2	SYSTEM TIMER	○	×	○	×

FIG.13

NODE ID	PARENT NODE ID	NODE TYPE	NODE NAME
100
101	100	GENERAL	LINE A
102	101	GENERAL	ROBOT A
103	101	GENERAL	ROBOT B
104	102	DATA REGISTRATION FUNCTION	DATA REGISTRATION
105	102	ALARM FUNCTION	ALARM
106	102	WARNING LIGHT FUNCTION	WARNING LIGHT
107

FIG.14

TIME	NODE ID	DATA TYPE	CHANNEL	VALUE
2001/01/01 00:00:00:001	104	VALUE	SHOULDER JOINT ANGLE	10
2001/01/01 00:00:00:001	104	VALUE	ARM JOINT ANGLE	20
...	104	VALUE

FIG.15

NODE ID	USER ID	NODE ID (FUNCTION)	USER NAME	VIEWING	CHANGE	EXE- CUTION	MANAGE- MENT
101	3	—	UNREGISTERED USER	×	×	×	×
101	11	—	ROBOT OPERATOR	○	○	○	○
101	12	—	ROBOT MAKER SUPPORT	○	×	×	×
101	—	2	SYSTEM TIMER	○	×	○	×

FIG.16

NODE ID	USER ID	NODE ID (FUNCTION)	USER NAME/ NODE NAME	VIEWING	CHANGE	EXE- CUTION	MANAGE- MENT
102	3	—	UNREGISTERED USER	○	×	×	×
102	11	—	ROBOT OPERATOR	○	○	○	○
102	12	—	ROBOT MAKER SUPPORT	○	×	○	×
102	13	—	ROBOT DATA TRANSMISSION APPARATUS MANAGER	○	○	○	×
102	—	2	SYSTEM TIMER	○	×	○	×
102	—	105	ALARM	○	×	○	×
102	—	106	WARNING LIGHT	○	×	○	×
102	—	9999	UNREGISTRATION FUNCTION	○	×	×	×

FIG.17




FIG.18





FIG.19





19/23




FIG.21






FIG.23

FIG.24




FIG.25

